



Jumper Settings:

- JP1: placed=enable Pull-Up
- JP2: placed = Enable Pull-Up
- JP3: placed = no shift. not placed=Shift I2C addresses left

Vanderhaegen Bart	
TITLE: I2C Bus Scanner	
Document Number:	REV:
Date: 1/07/2012 0:34:45	Sheet: 1/1